



Creator Series Mount Box




EN	For use with (products)	Dimensions	Weight
FR	Taille appropriée	Dimensions	Poids
ES	Tamaño adecuado	Dimensiones	Peso
DE	Geeignete Größe	Abmessungen	Gewicht
IT	Taglia Adatta	Dimensioni	Peso
PT	Tamanho Adequado	Dimensões	Peso
NL	Geschikte maat	Afmetingen	Gewicht
PL	Odpowiedni rozmiar	Wymiary	Waga
RU	Подходящий размер	Размеры	Вес
CN	合适的尺寸	尺寸	重量
JP	適切なサイズ	寸法	体重
AR	الحجم المناسب	الأبعاد	الوزن
CS Mount Box	C1S / C2S	280 x 280 x 127mm (11 x 11 x 5")	2.9 kg (6 lb 6 oz)
CM Mount Box	C1M / C2M / C2M-T2X	320 x 320 x 127mm (12 ^{5/8} x 12 ^{5/8} x 5")	3.3 kg (7 lb 4 oz)
CL Mount Box	C1L / C2L / C2L-T2X	360 x 360 x 127mm (14 ^{9/16} x 14 ^{9/16} x 5")	3.9 kg (8 lb 10 oz)
CL-D Mount Box	C3L / C3LA	360 x 360 x 186mm (14 ^{3/16} x 14 ^{3/16} x 7 ^{5/16})	4.9 kg (10 lb 13 oz)
WM Mount Box	W1M / W2M / W3M	619 x 290 x 113mm (24 ^{3/8} x 11 ^{7/16} x 4 ^{7/16})	4.4 kg (9 lb 11 oz)

Unboxing




Mounting Mount Box

1




2




Stick on feet*, cut grommet and pull cable through

3




Hook mount box, Fix remaining screws & cover screw holes

4




Wire up Quik-Link and install product

5



Attach grille firmly onto mount box*

6



*Original speaker grille is not required